

INSTRUCTION PACKAGE

MAKE YOUR CREATIVITY STICK

CRYSTALLIZED™ Flat Backs applications for fun and the long run

1. Everything you need to know about GLUING



Gluing is used for the application of CRYSTALLIZED™ Flat Backs No Hotfix, as well as for decorating accessories with special motifs, and applying Crystal-it to paper and cardboard.

1.1. Application of CRYSTALLIZED™ Flat Backs No Hotfix

You can use CRYSTALLIZED™ Flat Backs No Hotfix, for gluing onto gemstones, metal, plastic, wood and many other materials. Always make sure that the surface is clean and that you use the correct amount of glue. Use tweezers or a wax stick for applying the stone to the surface.

Steps:

- I. The surface must be cleaned properly before gluing.
- II. The glue should be applied with a dispenser.
- III. Pick up the stone with the tweezers.
- IV. Carefully place the stone in the correct position and press it down gently.

Hardening

Curing time and final gluing strength are dependent on the temperature. At room temperature the complete curing time is 24 hours. The time can be accelerated with warmth in an oven up to 1 hour (max. 100 °C / 212 °F).

